

---

**DEFINITIONS, TECHNICAL TERMS AND ABBREVIATIONS**

Cooperative	-	Presque Isle Electric & Gas Co-op acting through its authorized officers or employees within the scope of their respective duties.
Applicant	-	A person, firm or corporation applying for electric service from the Cooperative at one location.
Member-Consumer	-	A person, firm or corporation purchasing electric service from the Cooperative under these Rules and Regulations.
Line Extension	-	The installation of such facilities as poles, fixtures, transformers, wires and other appurtenances that are necessary to connect a new member or members to the Cooperative's distribution system.
Hertz	-	Cycle per second.
Kilowatt (kW)	-	Unit of electrical power representing rate of usage of energy; equivalent to 1,000 watts or approximately 1-1/3 horsepower.
Kilowatt-hour (kWh)	-	Unit of electrical energy equivalent to the use of one kilowatt for one hour.
Kilovoltampere (kVA)-		Unit of apparent electrical power which at 100% power factor is equivalent to one kilowatt.
Demand	-	the load at the terminals of an installation or system average over a specified period of time as expressed in terms of kW, KVA or other suitable units.
Power Factor (PF)	-	Ratio of kilowatt power to kilovoltampere apparent power.
Horsepower (hp)	-	Unit of mechanical power equivalent to 746 watts of electrical power or approximately 0.75 kW.
Month	-	Unless preceded by the word "calendar," the term "month" shall refer to a "billing month."
Billing Month	-	The period between two successive, scheduled meter readings when a member is billed under the provisions of a monthly rate schedule.

(Continued on Sheet No. A-6.01)

---

**DEFINITIONS, TECHNICAL TERMS AND ABBREVIATIONS**  
(Continued from Sheet No. A-6.00)

Year	Unless preceded by the word “calendar”, the term “year” shall refer to a “billing year”.
Billing Year	The period between two successive, scheduled meter readings, when a member is billed under the provisions of an annual rate schedule.
Permanent Residence	A member-consumer’s primary place of residence as evidenced by homestead exemption.
Seasonal Residence	A member’s secondary residence, not meeting the definition above of a “permanent residence”, which the member-consumer uses on a part-time, irregular or seasonal basis for such purposes as vacation, recreation, retreat, etc.
Standard Meter	A meter equipped with the hardware necessary to interact directly with the Cooperative’s Advanced Metering Infrastructure (AMI). All residential seasonal and commercial services are required to have a Standard (AMI) meter installed as part of their service.
Nonstandard Meter	Any meter that is not equipped with the hardware necessary to interact directly with the Cooperative’s AMI system. Residential Monthly accounts, Residential Service Schedule A may elect a nonstandard meter (Automated Meter Reading – AMR meter) which indirectly interacts with the Cooperative’s AMI system. A Nonstandard meter option is only available to Residential Monthly accounts, Residential Service Schedule A.
Member-Consumer Meter Readings	While the Cooperative installs its AMI system, member-consumers will be required to continue to read their meter on a monthly basis and provide -the actual reading to Cooperative on or before the due date.

(Continued on Sheet No. A-6.02)

---

Issued June 23, 2020  
By: Thomas J. Sobeck  
President and CEO  
Onaway, Michigan

Effective for service rendered on and  
**November 1, 2020**

Issued under the authority of the **Board  
of Directors dated 6/23/2020**